

Vibrating Alarm Watch

Charging

- . Remove the watch from the rubber strap
- . Using the USB cable (included) connect the watch to your power bank 5V or computer (some charging cable for Android phone also can do the charging)
- . A full charge takes about 2 hours(100 displayed), **Do Not Charge Overnight!**
- . A full charge can last 6-12 days, depends on the usage of the watch
- . To check vibration working or not, press any button while the watch is charging
- . When the battery is lower than 10%, the watch will be power off and reset after 2 days, **Charge In Time** to save all the setting!
- . Tips: The product is not waterproof, Do not wear in the shower or swimming pool. If got wet, the watch will be blinking or led lost, try to dry it with hairdryer or days later to charge

Basic Action

- . Check time: Press right button once
- . Check Months-Date: Press right button twice for Months-Date
- . Check battery percentage: Press right button 3 times (100 is full,reference value)
- . **To set any function, operate in 5 seconds of led display**

How to Set the Time

- . When screen is black, press **right** button once to see the current time
- . Quickly hold down the **right** button until only hours flashing, press the left button to increase the hours and right button to decrease the hours
- . When the hours are correct, quickly hold down the **right** button again until only minutes flashing, press the left button to increase the minutes and right button to decrease the minutes

- . When the minutes are correct, quickly hold down the **right** button again until 12-- or 24-- flashing, press any button to change the 12/24 hrs setting

How to Set Months/Dates

- . When screen is black, press **right** button twice to see Months-Dates
- . Quickly hold down the **right** button until only months flashing, press the left button to increase the months and right button to decrease the months
- . When the months are correct, quickly hold down the **right** button again until only dates flashing, press the left button to increase the dates and right button to decrease the dates
- . When the dates are correct, quickly hold down the **right** button again until the year flashing, press the left button to increase the year and right button to decrease the year

How to Set up to 15 Alarms

- . Press **left** button once: ALM (Alarm)
- . Press **left** button twice: 12:00 (Alarm 1 time)
- . Press **left** button three times: A1OF (Alarm 1 OFF)
- . Press **left** button over and over to go through all the 15 alarms (the sequence is ALM, Alarm 1 time, A1OF, Alarm 2 time, A2OF, Alarm 3 time, A3OF, ..., Alarm 15 time, 15OF)
- . **To set the alarm time:** press **left** button over and over when alarm 1 time appears, quickly hold down the **left** button until only hours flashing,press the left button to increase the hours and right button to decrease the hours, when the hours are correct, quickly hold down the **left** button again until only minutes flashing, press the left button to increase the minutes and right button to decrease the minutes
- . **To turn on/off the alarm:** when display is black, press **left** button over and over to see A1OF, then press **right** button to change A1ON / A1OF, OF=OFF (one sec vibration)

- . Continue to press **left** button to cycle through all the next alarms, repeat above to change the times and status of the next alarms

How to Set the Timer

- . **To turn on the timer,** when screen is black, press the **right** button over and over to see Cdn (countdown), 1min, 5, 10, 15, 20, 30, 45, 60, 90, 120, 180 min, when the desired timer length appears(15 or 30), quickly hold down the **right** button to turn on the timer
- . Press the **right** button when the screen is black to see the remaining time, press again is current time, again is battery percentage
- . **To turn off the timer,** When screen is black, press **right** button to see the remaining time, then quickly hold down the **right** button for 7 seconds until " OFF " appears

Note:

- . The vibration can be stopped immediately by press any button, or it will stop automatically in 30sec
- . The vibration time for Alarm 1 is 60 seconds, longer than other alarms, we recommend Alarm 1 to be wake up alarm, you also can set another two more alarms to support Alarm 1 to be snooze function
- . The alarms will be automatically repeat every day until it is turned off
- . When the 15 alarms goes off, silent vibration with time flashes to remind
- . When the timer goes off, silent vibration with no flashes to remind, totally discreet


MADE IN CHINA